



Infor LN Quality User Guide for Non-Conforming Report and Corrective Action Plan

Important Notices

The material contained in this publication (including any supplementary information) constitutes and contains confidential and proprietary information of Infor.

By gaining access to the attached, you acknowledge and agree that the material (including any modification, translation or adaptation of the material) and all copyright, trade secrets and all other right, title and interest therein, are the sole property of Infor and that you shall not gain right, title or interest in the material (including any modification, translation or adaptation of the material) by virtue of your review thereof other than the non-exclusive right to use the material solely in connection with and the furtherance of your license and use of software made available to your company from Infor pursuant to a separate agreement, the terms of which separate agreement shall govern your use of this material and all supplemental related materials ("Purpose").

In addition, by accessing the enclosed material, you acknowledge and agree that you are required to maintain such material in strict confidence and that your use of such material is limited to the Purpose described above. Although Infor has taken due care to ensure that the material included in this publication is accurate and complete, Infor cannot warrant that the information contained in this publication is complete, does not contain typographical or other errors, or will meet your specific requirements. As such, Infor does not assume and hereby disclaims all liability, consequential or otherwise, for any loss or damage to any person or entity which is caused by or relates to errors or omissions in this publication (including any supplementary information), whether such errors or omissions result from negligence, accident or any other cause.

Without limitation, U.S. export control laws and other applicable export and import laws govern your use of this material and you will neither export or re-export, directly or indirectly, this material nor any related materials or supplemental information in violation of such laws, or use such materials for any purpose prohibited by such laws.

Trademark Acknowledgements

The word and design marks set forth herein are trademarks and/or registered trademarks of Infor and/or related affiliates and subsidiaries. All rights reserved. All other company, product, trade or service names referenced may be registered trademarks or trademarks of their respective owners.

Publication Information

Release: Infor LN 2022.x

Publication Date: December 5, 2022

Document code: ln_2022.x_qmnonconfrepug__en-us

Contents

About this Guide.....4

 Contacting Infor.....5

Chapter 1: Introduction.....6

Chapter 2: Master Data set-up for NCR and CAP.....7

 Master data set-up for NCMR.....7

 Master data set-up for CAP.....8

Chapter 3: Non-Conformance and Disposition.....9

 Non-Conformance Report & Dispositions Process.....9

 Generating NCR.....10

 Non-Conformance in Service.....11

 Generating an NCR from a Service Object.....11

 Linking Service claims to a NCR.....12

 Linking a Disposition to Service Object.....13

 Linking a NCR to a Service Object.....13

 Handling quarantine inventory using NCR.....13

 Implementing Quarantine Handling.....14

 Using NCR for Handling Units in Quarantine.....15

Chapter 4: Creation of Corrective Action Plan.....17

 To create a Corrective Action Plan.....17

Index.....18

About this Guide

This document describes the purpose, setup, and use of non-conformance reporting (NCR) and corrective action plan (CAP).

Objectives

The objectives of this book are to describe the purpose of Non-Conforming Report & Corrective Action Plan, and how to create and use master data.

Intended Audience

This guide is intended for those who want to learn how to use the Non-Conforming Report & Corrective Action Plan, and how to set-up master data in a way that best serves their purposes. Both end users and users on administrator level will find the information they require.

Assumed Knowledge

Familiarity with the business processes involved in handling inspections, and general knowledge of the LN functionality will help you understand this guide. In addition, Quality training courses are available to give you a headstart.

Document summary

The first chapter, Introduction, describes the purpose and the general characteristics of Quality package.

The following chapters deal with the master data setup for NCR and CAP, describe how NCR and CAP are created.

How to read this document

This document was assembled from online Help topics. As a result, references to other sections in the manual are presented as shown in the following example:

Please refer to the Table of Contents to locate the referred section.

Underlined terms indicate a link to a glossary definition. If you view this document online and you click on underlined text, you jump to the glossary definition at the end of this document. Non-underlined references do not represent a link to glossary definitions or other elements.

Contacting Infor

If you have questions about Infor products, go to Infor Concierge at <https://concierge.infor.com/> and create a support incident.

The latest documentation is available from docs.infor.com or from the Infor Support Portal. To access documentation on the Infor Support Portal, select **Search > Browse Documentation**. We recommend that you check this portal periodically for updated documentation.

If you have comments about Infor documentation, contact documentation@infor.com.

Chapter 1: Introduction

Quality Management helps manufacturing and process industries to monitor and improve the quality of their products. The Quality Management helps industries perform regular inspection procedures to attain the required quality. In every company, products, including raw materials, end products, and products in between manufacturing steps, are regularly inspected to ensure that procedure runs smoothly, to review what went wrong, or to determine what could go wrong during production, distribution, or in the time that products are in inventory. Quality uses logistical flow of products to schedule inspections.

LN Quality supports quality management throughout the entire company. Quality manages the activities that are required to control the flow of products selected for inspection. It also supports the quality control of intermediate products and end products.

Quality Management is linked to other LN modules and packages at various points in the production process to provide extensive quality checks.

Chapter 2: Master Data set-up for NCR and CAP

This chapter explains the data set-up that is required to generate NCR and CAP.

Master data set-up for NCMR

As part of the master data set-up you must define:

- The Non-Conforming Material Types to classify a non-conformance.
- The Severities that highlight the seriousness of a non-conformance.
- The Material Review Boards responsible for evaluation of NCMR.
- The reason for the non-conformance.

Parameter settings

To implement the Quality functionality, select the **Quality Management (QM)** checkbox in the Implemented Software Components (tccom0100s000) session.

Use the Quality Management Parameters (qmptc0100m000) session to define and set the following.

- The **Non-Conformance Implemented** check box is checked, to implement the NCMR functionality.
- The code of the default number group of the series used to generate the NCMR number.
- The code of the default series used for generating the NCMR number.
- The **Log History** check box to track the changes made to the NCMR.

Data set-up

To set-up master data:

- Define the types of non-conforming material using the Non-Conformance Material Types (qmncm0101m000) session.
- Define the severity of non-conforming material using the Severities (qmncm0102m000) session.
- Define the material review board and owner of the material review board for the non-conforming material using the Review Boards (qmncm0103m000) session.
- Define the reason for non-conformance using the Non-Conformance Cause (qmncm0104m000) session.

Master data set-up for CAP

In the master data for corrective action plan (CAP) you can define:

- The task types that categorize the kind of corrective action that must be performed, using a task.
- The categories to classify the CAP.

Parameter settings

To implement the Quality functionality, select the **Quality Management (QM)** checkbox in Implemented Software Components (tccom0100s000) session.

Use the Quality Management Parameters (qmptc0100m000) session to define and set the following:

- The **Corrective Action Plan Implemented** check box to implement the CAP functionality.
- The code of the default number group of the series used for generating the CAP number.
- The code of the default series used for generating the CAP number.
- The step size used to increase the task number that is defined in the Corrective Action Plan - Tasks (qmcpl1505m000) session.
- The **Log History** check box to track the changes made to the CAP.

Data set-up

To set-up master data:

- Define the task types that categorize the kind of corrective action that must be performed using the Task Types (qmcpl0101m000) session.
- Define the categories to classify the CAP using the Categories (qmcpl0102m000) session.

Chapter 3: Non-Conformance and Disposition

This chapter provides a detailed explanation about the generation of NCR.

Non-Conformance Report & Dispositions Process

Non-Conformance Report (NCR) functionality allows you to report non-conforming material identified during inspection of items or material (Quality or Warehouse Inspection) or during the movement of the materials and/or when the material is in stock. The material is inspected to verify that the items conform to the relevant specifications and/or drawings. During the material inspection process, if a non-conformance is detected, the material is immediately isolated.

This process is applicable to material that is purchased, issued for a production order, finished goods from a production order, issued a material for a sales order and so on.

The NCR is generated for following order origins with or without quality inspections executed as part of quality management.

- Purchase
- Purchase Schedule
- Sales
- Sales Schedule
- SFC Production
- ASC Production
- Transfer
- Project Contract
- Project
- EP Distribution
- Storage Inspection
- Service
- Maintenance Work
- Batch Repair
- Service Call

Generating NCR

The NCR can be generated from:

- Warehouse Inspection
- Quality Inspection
- Storage Inspection
- Service
- Manually

Complete the following steps to create NCR:

1 Generate NCR

Use the Non-Conformance Reports (qmncm1100m000) session to maintain the details of NCR. Based on the order origin LN displays the order details.

If NCR is created manually enter the order origin.

- Enter the details relating to source order data (if required), lot identifiers, a description of the material non-conformance, some categorization of the non-conformance and information relating to the reporter.
- Enter the details of Material Review Board and owner of the NCR who is responsible for the NCR.

The NCR is created with status open irrespective of the order origin.

To retain the traceability, LN allows you to define a parent child relationship between two NCRs. If you use Split NCR option, LN refers to the existing NCR as a parent and the subsequent NCR as a child.

If NCR is not generated manually, LN defaults order details based on the order origin.

You can select and link multiple lots and/or serial numbers to an individual NCR.

2 Submit the NCR

Use the Submit NCR option in the Non-Conformance Reports (qmncm1100m000) session to submit the NCR for a completeness check, routing decision, and to identify the individual responsible for carrying out the non-conforming material disposition. You can change the default NCR report owner and/or the default Material Review Board (MRB).

To change the data you can reset the NCR status from **Submitted** to **Open**.

3 Assign NCR

Use the Assign NCR option in the Non-Conformance Reports (qmncm1100m000) session to assign the NCR with status **Submitted**.

To incorporate the changes suggested by the owner of the material review board, you can change the status from **Assigned** to **Submitted**.

4 Disposition of the NCR

The responsible person/ owner investigates the material non-conformance and if required re-assigns the NCR to another owner or MRB in the Details Tab of Non-Conformance Reports (qmncm1100m000) session.

The NCR can be set to the following pre defined dispositions:

- **Rework (to Existing Specification):** This disposition is for non-conforming material that can be reworked without adverse effect on safety, performance, interchangeability, reliability, or quality. The reworked material is returned to the normal flow of material.

- **Rework (to New Specification):** This disposition is for non-conforming material that can be reworked without adverse effect on safety, performance, interchangeability, reliability, or quality. LN assigns a new part number.
- **Reclassify:** This disposition involves the reclassification of non-conforming material and the assignment of a new part number.
- **Return to Vendor:** This disposition is applicable when the material discrepancy is the responsibility of the supplier and other dispositions are not recommended.
- **Scrap:** The non-conforming material cannot be used for its intended purposes and cannot be repaired. Proof of scrapping is required.
- **Use as is:** Is for items, parts or products for which minor nonconformance is repeated, which can be ignored.
- **Repair:** This disposition is to bring the nonconforming material to an acceptable condition but which may not totally conform to the applicable drawings or specifications.
- **No Fault Found:** This disposition is used when the non-conformance is reported erroneously. Material of this disposition is returned to the normal flow.

You cannot change a NCR with status **Dispositioned** to a previous status.

5 Close NCR

Select the Close NCR option to close the NCR and status automatically changes to **closed**.

Non-Conformance in Service

You can generate a Non Conformance Report (NCR) for a Service object or link a service object to an existing NCR.

A new General Service Parameter is added to implement the NCR functionality in Service. This parameter can only be selected if the **Quality Management (QM)** check box is selected in the **Implemented Software Components (tccom0100s000)** session and if the **Material Non-Conformance** check box is selected in the **Quality Management Parameters (qmptc0100m000)** session.

You can generate the NCR for service objects. You can also link an NCR from Quality to a Service object. You can link one or multiple NCRs for the following Service objects:

- Service Call
- Service Order
- Maintenance Work
- Batch Repair
- Claims

Generating an NCR from a Service Object

To generate an NCR from a service object:

- 1 In the **Work Order (tswcs2100m100)** session, select an outgoing subassembly line.
- 2 In the **Actions** menu, click **Create Non-Conformance Report**. The **Non-Conformance Reports (qmncm1100m000)** session opens. LN generates a NCR number for the order.
LN defaults the following:
 - Item Details. If the item is serialized, click the **Lots / Serials / Stock Point Details** button to view the serial details in **Non-Conforming Material Report - Lots and Serials (qmncm1110m000)** session.
 - Origin Order Details
 - Order Origin
 - Line Type
 - Order Line
 - Business Partner
 - Warehouse
- 3 In the **Non-Conformance Reports (qmncm1100m000)** session, specify the following:
 - **Description of Material Non-Conformance**
 - **Non-Conforming Type**
 - **Non material Severity**
- 4 Save and Submit NCR. In the Outgoing Subassembly tab of Work Order (tswcs2100m100) session, select References menu and click Related Orders. In Work Order – Related Orders (tsmdm4500m000) session, you can view the details of the NCR that was created.
- 5 In the **Disposition** tab of the **Non-Conformance Reports (qmncm1100m000)** session, specify the following:
 - **Review Board**
 - **Planned Review Date**
- 6 Save, Submit, and Assign the disposition.
- 7 Select the **NCR Disposition**. The allowed values for Service are:
 - **Rework (to Existing Specification)**
 - **Rework (to New Specification)**
 - **Repair****Note:** You must select the disposition type in order to specify the Kind of Order.
- 8 Select the **Disposition Order Origin**. For Service, the following values are applicable:
 - **Service**
 - **Maintenance Work**
 - **Batch Repair**
 - **Maintenance Sales**
- 9 Click **Disposition**. Based on the value specified in the Kind of Order, LN generates the required order.

Linking Service claims to a NCR

To link an NCR to a supplier claim:

- 1 In the **Supplier Claims (tscmm2100m000)** session, select a claim.
- 2 Click **Link Non-Conformance Report** option. The **Non-Conformance Reports (qmncm1100m000)** session opens.
- 3 Select the NCM that you want to link to the supplier claim.

Linking a Disposition to Service Object

To link a service object to a disposition order:

- 1 In the **Non-Conformance Reports (qmncm1100m000)** session, select and open a NCR of any order origin.
- 2 In the **Disposition** tab, specify the service object in the **Disposition Order Origin** field. For example, Maintenance Sales Order.
- 3 In the **Non Conformance Disposition Code** field, select the order number for the service object. For example, maintenance sales order number.
- 4 Save the NCR.

Linking a NCR to a Service Object

To manually create an NCR for a Service object:

- 1 In the Non-Conformance Report (qmncm1100m000) session, select the order origin. The order origin can be:
 - Service
 - Maintenance Work
 - Batch Repair
 - Service Call
- 2 The order origin represents the activity during which the non-conformance is identified. From the NCR, the you can access the Service sessions based on the order origin you select. For each origin, a filter is applied, so that orders with Released status only, are displayed. For the order origins, Maintenance Work Order and Batch Repair, the order line type determines the sessions you can access. The order line type can be Material Line, Incoming Subassembly and Outgoing Subassembly

Handling quarantine inventory using NCR

If a defect (non-conformance) is established during purchase, routing or production process, you can either scrap, reject or move the item to a quarantine inventory location. The items in the quarantine inventory can be assessed using the following dispositions:

- **Return to Vendor**
- **Rework (to New Specification)**
- **Rework (to Existing Specification)**
- **Reclassify**
- **Scrap**
- **Use as is**

To execute this disposition, a non-conformance report (NCR) can be generated for this item in quarantine inventory. If an NCR is generated for items in quarantine, disposition is not specified in the Quarantine inventory in Warehousing. This data is defined in the **Non-Conformance Reports (qmncm1100m000)** and is referenced by the quarantine inventory in Warehousing.

Implementing Quarantine Handling

You can follow these steps to implement quarantine handling:

- 1** In the **Item - Warehousing (whwmd4500m000)**, select the **Scrap and/or Quarantine** or the **Quarantine** option for an item.
- 2** In the **Testing Combinations (qmptc0119m000)** session, create a combination for the required item and the standard test procedure.
- 3** In **Purchase Order (tdpur4100m900)** session, create and approve a purchase order for the item.
- 4** In the **Warehouse Receipt (whinh3512m000)** session, confirm the warehouse receipt.
- 5** In the **Inspection Order (qmptc1100m100)** session, specify the test data for the inspection order lines and complete the inspection order.
- 6** In the **Inspection Order (qmptc1100m100)** session, the **Result** of the **Order Inspection (qmptc1620m000)** session can be set to **Partially Accepted/ Rejected**.
- 7** Complete and process the order inspection.
- 8** In the **Warehouse Inspection (whinh3622m000)** session:
 - Review the accepted and rejected items defaulted by LN from the **Order Inspection (qmptc1620m000)** session.
 - Process the warehouse inspection.
 - Click quarantine inventory.
- 9** In the **Quarantine Inventory (whwmd2671m000)** session:
 - Review the number of items that are quarantined.
 - Click **Report** to create a non-conformance report for the rejected quantity.

Note If a Non-conformance is already created for warehouse inspection, the same NCR is linked to Quarantine Inventory when quarantine inventory is created.
- 10** In the **Non-Conformance Reports (qmncm1100m000)** session, disposition the non conformance. For more information on how to execute the non-conformance, refer to Non-Conformance Report & Dispositions Process.

Note

- You can use the split NCR option to create individual NCRs based on the requirement, for the items in quarantine.
 - If the **NCR Disposition** field is set to **Reclassify** or **Rework (to New Specification)** you can specify a **To Item** to which the non-conforming item must be transferred.
- 11** After disposition, LN updates the **NCR Disposition**, **Reason** and **To Item** fields in the **Quarantine Inventory (whwmd2671m000)**.
- 12** In the **Quarantine Inventory (whwmd2671m000)** session:
- Review the disposition lines.
 - Process the quarantine inventory order.
- LN creates a disposition order and defaults this value in the **Disposition Order** and **Disposition Order Origin** fields in the **Non-Conformance Reports (qmncm1100m000)** session.
- 13** Close the **Non-Conformance Reports (qmncm1100m000)** session.

Using NCR for Handling Units in Quarantine

The quarantine inventory can be managed using handling units. If a handling unit is linked to an NCR, LN splits the NCR based on the handling units and not on the basis of lots and serials.

A handling unit can be linked to an NCR only if the if the stock point details (serials, lot, quantity etc.) are the same.

Processing quarantine inventory for an NCR with handling units

- 1** In the **Item - Warehousing (whwmd4500m000)**, select the **Scrap** and/or **Quarantine** or the **Quarantine** option, for an item.
- Note** If the **scrap** option is selected, the Quarantine Inventory command is disabled.
- 2** In the **Testing Combinations (qmptc0119m000)** session, create a combination for the required item and the standard test procedure.
- 3** In the **Purchase Order (tdpur4100m900)** session, create and approve a purchase order the for the item.
- 4** In the **Warehouse Receipt (whinh3512m000)** session:
- Click the Generate Handling Unit option to create a handling unit for the specified warehouse receipt line.
 - Click the Handling Unit option to generate the lots and serials for the item.
 - Confirm the warehouse receipt.
- Note** You cannot confirm the warehouse receipts until the lots and serials are generated for the item linked to the handling unit in the **Handling Units (whwmd5130m000)** session.
- 5** In the **Inspection Order (qmptc1100m100)** session, specify the test data for the inspection order lines and complete the inspection order.
- Note** The test data is specified only for the items and not the handling unit.
- 6** In the **Inspection Order (qmptc1100m100)** session, the **Result** of the **Order Inspection (qmptc1620m000)** session can be set to **Partially Accepted/ Rejected**.

- 7 Complete and process the order inspection.
- 8 In the **Warehouse Inspection (whinh3622m000)** session:
 - Review the accepted and rejected items defaulted by LN from the **Order Inspection (qmptc1620m000)** session .
 - Review if the **Handling Unit(s) Present** check box is selected and the **Handling Unit** field is defaulted by LN.
 - In the Handling Unit tab:
 - Click Inspect Handling Unit option.
 - In the **Inspect Handling Unit (whinh2234m000)** session:
 - Specify the handling unit and click **Stock Point Details** button.
 - In the **Handling Unit Stock Point Details (whwmd5136m000)** session, view the lot/serial item linked to the handling unit and specify if the item is accepted or rejected based on the inspection order data.
 - Review the accepted/rejected quantity defaulted in the Handling Unit tab.
 - Process the warehouse inspection. **Note** You cannot process the warehouse inspection if the inspection details for the lots and serials do not match the inspection results of the handling units.
 - Click the quarantine inventory option.
- 9 In the **Quarantine Inventory (whwmd2671m000)** session:
 - Review the number of items that are quarantined.
 - Click **Report** to create a non-conformance report for the rejected quantity.

Note If a Non-conformance exists for warehouse inspection, this NCR is linked to Quarantine Inventory when created.
- 10 In the **Non-Conformance Reports (qmncm1100m000)** session, disposition the non conformance. For more information on how to execute the non-conformance, refer to Non-Conformance Report & Dispositions Process.
 - You can use the Split NCR option to create individual NCRs based on the disposition requirement, for the items in quarantine. LN splits the NCR, based on the handling units.
 - If the **NCR Disposition** field is set to **Reclassify** or **Rework (to New Specification)** you can specify a **To Item** to which the non-conforming item must be transferred.
- 11 Click the **Handling Units** option to view the handling units linked to an NCR in the **Non-Conformance Handling Units (qmncm1120m000)** session. **Note** You must specify values in this session, if multiple NCRs are linked to the Quarantine Inventory.
- 12 After disposition, LN updates the **NCR Disposition, Reason** and **To Item** fields in the **Quarantine Inventory (whwmd2671m000)** session.
- 13 In the **Quarantine Inventory (whwmd2671m000)** session:
 - Review the disposition lines.
 - Process the quarantine inventory order.

LN creates a disposition order and defaults this value in the **Disposition Order** and **Disposition Order Origin** fields in the **Non-Conformance Reports (qmncm1100m000)** session.
- 14 Close the **Non-Conformance Reports (qmncm1100m000)** session.

Chapter 4: Creation of Corrective Action Plan

This chapter provides a detailed explanation about the generation of CAP.

To create a Corrective Action Plan

The Corrective Action Plan (CAP) executes the actions required to prevent non-conformance/ failure from recurring.

1 Create CAP and CAP tasks

- a** You can create CAP manually or generate CAP from NCMR. Use the Corrective Action Plan (qmcpl1100m900) session to create a CAP.
- b** LN generates CAP number based on the data set in **Number Group** and **Default Series** field in Quality Management Parameters (qmptc0100m000) session. Enter the details such as completion date of the CAP, owner of the CAP, approver of the CAP, item, business partner and so on.
- c** Define the CAP tasks in task lines with estimated start and due dates.

2 Submit the CAP

When the CAP tasks are identified, you can submit the CAP for approval. The CAP status changes to Submitted.

3 Approve the CAP

The approver of the CAP approves the CAP. LN sets CAP status to Approved. The status of the tasks in task lines changes to Approved.

4 Execute and complete CAP tasks

Use the start task option to start CAP tasks in task lines. When you start the task status changes to In Progress. During task is in progress you can add text, document, enter the completion date and change the status to open or completed.

Verify and close the CAP task

- After completing the CAP tasks, verify the tasks and close. Verify the task in Task tab available in Corrective Action Plan (qmcpl1100m900) session. Use close task option to close the task.

5 Close CAP

Evaluate the CAP after the CAP tasks are closed and close the CAP.

Index

C

CAP [17](#)
Corrective Action Plan [17](#)

M

Master data set-up for CAP [8](#)

Master data set-up for NCMR & CAP [7](#)

N

NCMR [9](#)
Non-conformance
Service [11](#)
Non-Conformance Material Report [9](#)